




Sierra Data Sheet

Sierra Heated Towel Rail

Towel Rail Installation

- Read the instruction sheet carefully before installation.
- Installation should be completed by professional person.
- Please dispose the package properly.



All Vaporo radiators are BOE and pipe centres are the radiator width plus 74mm.

If used with Vaporo Valves.

Please note due to manufacturing tolerances pipe centres may vary by +/- 10mm, we recommend that pipe work is not altered until your radiator is on site.

All Affinity Radiators: **Test Pressure:** 7 bar **Max Operating Pressure:** 6 Bar







Sierra Data Sheet

Sierra Heated Towel Rail

Electricity



Water



All Vaporo radiators are BOE and pipe centres are the radiator width plus 74mm.

If used with Vaporo Valves.

Please note due to manufacturing tolerances pipe centres may vary by +/- 10mm, we recommend that pipe work is not altered until your radiator is on site.

All Affinity Radiators: **Test Pressure:** 7 bar **Max Operating Pressure:** 6 Bar

